

**Stone Ledge Fountains  
(2 pieces)  
COMPONENTS AND PARTS LIST**

March 20, 2019



**Water Feature  
(Disc)**

**Basin**

**Fountain holds  
approximately 1-3  
gallons of water**

**Pump Kit Parts List**

PK120-FG pump (1)  
20" length of 1/2" Black Non-kink tubing (1)  
Hose clamps (2)  
1 tube clear silicone

**Tools you will need**

Level



**This fountain takes cover  
FTNCOV-SM**

# Stone Ledge Fountains (2 pieces)

March 20, 2019

## ASSEMBLY INSTRUCTIONS

1. Make sure you are assembling your fountain on a level surface.
2. Connect the transformer (Fig A) to the single male plug on the connection cord (Fig B).
3. Feed the connection cord through the standpipe in the basin leaving enough cord length inside basin to work with the pump sitting flat in the bottom of the bowl. Leave the transformer outside of the bowl.
4. Feed the cord for the light spout through the top of the fountain disc.
5. Connect the light spout (Fig C) and pump (Fig D) to the double female plug on the connection cord.
6. Insert the light spout in the top of the fountain disc so it sits on the attached shelf, flush with the top surface of the disc, and secure with silicone.
7. Place a hose clamp over each end of the 1/2" non-kink tubing.
8. Insert one end over the pump water outlet and secure with the hose clamp.
9. Place the other end of the 1/2" non kink tubing over pipe extending down from light spout in the fountain disc and secure with the clamp.
10. Before adding water
  - a. Let the silicone dry for 24 hours.
  - b. Be sure the basin is level.
  - c. Note – Do not fill water over the top lip of the stand pipe.
11. Place the water feature on top of the basin making sure that the water feature is level.
  - a. Note – do not allow pump to run dry as it will cause damage to the pump.



**Fig A**



**Fig B**



**Fig C**



**Fig D**

## WINTER CARE AND GENERAL FOUNTAIN INSTRUCTIONS

### **- W I N T E R   C A R E -**

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with a breathable, lightly colored material (fountain covers sold by Campania International are recommended), making sure that water will not accumulate in the basin or other fountain component and freeze.
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

### **- G E N E R A L   F O U N T A I N   T I P S -**

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

March 20, 2019

For more Campania product information visit [www.campaniainternational.com](http://www.campaniainternational.com)