

# FT-131 Cascade Fountain

**Three people are recommended for the installation of this fountain!**



## Pump Kit Parts List

PK 300 Pump (1)  
#10 stopper (1)  
Approx. 18" length of 1/2" Black Non-Kink tubing (1) \*\*  
Approx. 2" length 5/8" clear vinyl tube (1) \*\*  
Approx. 2" length 1/2" of CPVC pipe (1) \*\*  
Wedges (4)  
Hose clamps (3) \*

\* Hose clamps may be used as flow restrictors

\*\*Black non-kink tubing and clear vinyl tubing have been preassembled

### FOUNTAIN INFORMATION:

**This fountain holds approximately 6 gallon of water.**

**This fountain uses a small fountain cover.  
(FTNCOV-SM)**

**Compatible with #10 Refill Device  
(A special stopper is required to use the refill kit for  
this fountain.)**

### TOOLS REQUIRED:

**Bubble Level** 

### PUMP INFORMATION:

**OEMPF320 - 320 GPH Pump  
16 FT cord length**

## - W I N T E R   C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

## - G E N E R A L   F O U N T A I N   T I P S -

**Install fountains on a level surface.** You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

**All of our cast stone is proudly**




Check out YouTube for a "How to" video.  
For more Campania product information visit [www.campaniainternational.com](http://www.campaniainternational.com)


# FT-131 Cascade Fountain

## Three people are recommended for the installation of this fountain!


Assemble your fountain on a level surface capable of holding a minimum of 586 pounds with an approximate 1.5 square foot footprint.




FT-131F (50 lbs)  
18"W x 4.5"H




P-502 (198 lbs)  
39.5"W x 9.75"H




FT-131C (25 lbs)  
11.5"W x 7"H



FT-131B (113 lbs)  
29.25"W x 8"H



FT-131A (28 lbs)  
18"W x 4.5"H



FT-131D (2 lbs)  
5"L x 1.5"W x 4.75"H

1. Place the base (FT-131F) into position where the fountain will be installed, ensuring that it is level.
2. Center the Zen Bowl (P-502) over the base (FT-131F)
3. Assemble the pump kit
  - a. Attach the 1/2" non-kink tubing to the pump outlet.
  - b. Place the stopper around the pump cord approximately 8" from the pump.
4. Feed the pump cord through the hole in the Zen Bowl (P-502) and the channel in the base (FT-131F).
5. **FIRMLY** press the stopper into the hole evenly.
  - a. Note: Using the handle of a screwdriver or hammer works best to press the stopper in place.
6. Place the pump house (FT-131C) over the pump and in the center of the Zen Bowl (P-502).
7. Feed the tubing that is connected to the pump through the center of the middle bowl (FT-131B).
8. Center the middle bowl (FT-131B) over the pump house (FT-131C).
9. Insert the CPVC pipe connected to the tubing into the PVC coupling in the bottom of the top bowl (FT-131A).
10. Center the top bowl (FT-131A) over the middle bowl (FT-131B).
11. Fit the pump house door (FT-131D) into the pump house (FT-131C).
12. Fill the fountain with water.