

FT-276 LC2 Fountain

Three people are recommended for the installation of this fountain!



FOUNTAIN INFORMATION:

This fountain holds approximately 55 gallons of water.

This fountain uses a medium fountain cover.
(FTNCOV-MED)

Compatible with #10 Refill Device and LED Kits
(A special stopper is required to use the refill kit for
this fountain.)

Pump Kit Parts List


PK800 pump (1)
#10 stopper (1)
Approx. 40" length of 5/8" non-kink tubing (1) **
Approx. 2" length of 3/4" clear vinyl tubing (1) **
Copper Spillers (3)
2.8 oz. tube of silicone (1)
Wedges (2)
Hose clamps (2) *

* Hose clamps may be used as flow restrictors

**The internal tubing has been preassembled

TOOLS REQUIRED:

Bubble Level



PUMP INFORMATION:

PP800 - 800 GPH Pump
16 FT cord length

- WINTER CARE -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise, components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to ensure that plastic is secure and water is not accumulating in any fountain component.

- GENERAL FOUNTAIN TIPS -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

All of our cast stone is proudly



Made in USA


Check out YouTube for a "How to" video.

For more Campania product information visit www.campaniainternational.com


FT-276 LC2 Fountain

Three people are recommended for the installation of this fountain!

Assemble your fountain on a level surface capable of holding a minimum of 960 pounds with an approximate 7 square foot footprint.




FT-275D (277 lbs)
35.75"L x 35.75"W x 9.5"H



FT-276B (196 lbs)
17.5"L x 17.5"W x 33"H



FT-276A (9 lbs)
14"L x 14"W x 1"H



FT-276E (4 lbs)
9.5"L x 9.5"W x 1"H



FT-276C (4 lbs)
6.75"L x 1.5"W x 5.75"H

1. Place the basin (FT-275D) into position where the fountain will be installed, ensuring that it is level.
2. Assemble the pump kit
 - a. Connect the preassembled tubing to the pump by sliding the 3/4" clear tubing over the pump outlet.
 - b. Place the stopper around the pump cord approximately 8 inches from the pump.
3. Feed the pump cord through the hole in the basin (FT-275D) and the channel.
4. **FIRMLY** press the stopper into the hole evenly.
 - a. Note: Using the handle of a screwdriver or hammer works best to press the stopper in place.

5. Run a continuous bead of silicone around the ledge on the inside of the column (FT-276B). (See picture to right.)
6. Use the silicone to attach the copper spillers
 - a. Clean away any excess silicone around the spillers.



7. Secure the tubing connected to the pump to the pipe protruding from the bottom of the water outlet disc (FT-276A).
8. Press the water outlet disc (FT-276A) into the column (FT-276B) and press lightly into the silicone.

9. Place the water controller disc (FT-276E), detail side up, onto the water outlet disc (FT-276A).

10. Place the pump cover door (FT-276C) into the pump access hole of the column (FT-276B).

11. Let the fountain sit 24 hours before filling with water.