

GFRFCFT-1101 Brentwood Fountain (1 pieces)

Revised January, 2019

COMPONENTS AND PARTS LIST



31"L x 22"W x 66"H
220 lbs

Pump Kit Parts List

PK300 pump (1)
6" length of 1/2" Black Non-kink tubing (1)
2" length of 3/8" copper pipe
#5 Drain stopper (1)
Hose clamps (2) *

* Hose clamps may be used as flow restrictors

Tools you will need

Level 

This fountain uses fountain cover
FTNCOV-XLG

GFRCFT-1101 Brentwood Fountain (1 pieces)

Revised January, 2019

ASSEMBLY INSTRUCTIONS

1. Make sure you are assembling your fountain on a level surface.
2. Assemble the pump kit
 - a. Attach one end of the non-kink tubing to the pump.
 - b. Insert the 2" copper pipe provided about 1" into the 1/2" end of the tubing assembly.
 - c. Secure the copper pipe into place with a hose clamp.
3. Place the assembled pump kit into the basin next to the hose protruding from the inside back of the fountain.
4. Fit the copper pipe that you attached to the tubing assembly into the tubing protruding from inside the fountain.
5. Feed the pump cord through the hole in the back of the fountain.
6. Fit the #5 drain stopper into the drain hole.
7. Fill the fountain with water.

WINTER CARE AND GENERAL FOUNTAIN INSTRUCTIONS

- W I N T E R C A R E -

Fountain bowls/tops and other fountain components, which collect water, should not be left outside in the winter since any component, which fills with water and freezes may crack. Likewise components such as pedestals, which remain in a basin, filled with water, which then freezes, may also crack or crumble. Ideally, therefore, a fountain should always be stored indoors or in a dry protected place such as a covered porch away from the elements. However, if a fountain must be left outside:

- (1) Remove pump, rubber stoppers, drainpipes, finials, and other small components for storage indoors. Note that stoppers or drainpipes are removed to allow drainage in the event water accumulates in any basin.
- (2) Raise fountain base from ground with wood strips so that base will not freeze to the ground surface.
- (3) Cover or wrap the fountain with burlap or other absorbent material (old blanket or towel) and then cover securely with plastic, making sure that water will not accumulate in the basin or other fountain component and freeze;
- (4) Check fountain periodically to insure that plastic is secure and water is not accumulating in any fountain component.

- G E N E R A L F O U N T A I N T I P S -

Install fountains on a level surface. You will need a properly grounded 110-volt (AC only) GFCI protected receptacle near the fountain for your pump. All pumps are submersible and must be completely underwater to function properly. Test all pumps and adjust to full output prior to assembly. It is not recommended that fountains be placed directly on grass or dirt. Position the channel opening at the base of each fountain toward the electrical outlet to be used since the pump cord will be threaded through this opening.

For more Campania product information visit www.campaniainternational.com